

# HOROLOGICAL LAB HOROLOGICAL MACHINE N°3 FROG

HOROLOGICAL MACHINE N°3 FROG


**FUNCTIONS** 

OPERATING INSTRUCTIONS

TIME SETTING

DATE SETTING

### HOROLOGICAL MACHINE N°3 FROG



## **FUNCTIONS**

- . Hour
- 2. Minute
- Date ring
- 4. Date indicator


# Position 1

### OPERATING INSTRUCTIONS

### I. WINDING

Your watch is equipped with an automatic movement and a screwed-down crown.

If it has stopped, turn the crown anticlockwise to slide the crown out and wind the crown a few turns (clockwise).




### OPERATING INSTRUCTIONS

### 2. TIME SETTING

 $\,$  « Out » position: turn the crown anticlockwise and slide it fully out. Turn the crown to correct time.

### HOROLOGICAL MACHINE N°3 FROG



### OPERATING INSTRUCTIONS

### DATE SETTING

To adjust the date, gently position the supplied tool in the corrector hole, which is located on the right-hand side of the case.

Warning: to avoid damaging the date gear train, do not adjust the date between  $8.00\ p.m.$  and  $3.00\ a.m.$