

MB&F

LMX

LMX

Functions

05

Operating instructions - Winding

07


Adjustable power reserve indicator

09

Operating instructions - Time setting

11


LMX



Functions

- 1 First time zone
- 2 Second time zone
- 3 Adjustable power reserve indicator


LMX



Operating instructions - Winding

Your watch is equipped with a manual winding movement. If it has stopped, wind the second time crown (B) in position "in". The power reserve cage (C) will turn and the indicators will rise till the maximum power reserve capacity "M" or "7". When the indicators drop to "S" or "1" the capacity is empty.

LMX




Operating instructions - Winding

When the indicators are completely raised, the capacity is full (7 days power reserve). Note that the cage will turn when winding your watch, allowing you to choose the orientation of the power reserve indication. One of the indicators is indexed with the days of the week (M-T-W-T-F-S-S) while the other is numbered 7 to 1.

If you choose to coordinate your watch with the day of the week, you will need to wind your watch fully on Monday morning. Alternatively, the numbers 7 to 1 correspond to the number of days of power reserve, if you choose not to coordinate your watch with the day of the week.

LMX



Operating instructions - Time setting

Crown (A) position "Out": Turn the crown to set the first time zone. Slide the crown back against the case when finished.

Crown (B) position "Out": Turn the crown to set the second time zone. Slide the crown back against the case when finished.

Important: to ensure the proper setting of your watch, you should first advance the minute hand approximately 10 minutes clockwise past the desired time, and then return the minute hand backwards (counter-clockwise) to the exact time.

